

ASSEMBLY INSTRUCTIONS

LC Series



Large Capacity Drawer
Model #SPT336



Large Capacity Drawer
Model #SPT348






Large Capacity Drawer
Model #SPT360



Large Capacity Drawer
Model #SPT372

HARDWARE DESCRIPTION

PART #	IMAGE	DESCRIPTION	QTY
0050136		#10 x 3/4" Phillips Pan Head	4
0050966		#8 x 3/8" Phillips Truss Head	14
0052346		#8-32 x 3/8" Phillips Pan Head Thread Forming	1



ASSEMBLY INSTRUCTIONS

REQUIRED WALL OPENING


Large Capacity Drawers

Model #SPT336

Model #SPT348

Model #SPT360

Model #SPT372



STEP 1


Insert Drawer Into Wall Opening 3/4" From The Exterior.
Attach Exterior Trim To The Drawer Housing.

STEP 2

Slide In The Remainder Of The Drawer
Until Trim Is Tight Against The Wall.

STEP 2

From The Interior, Extend The Drawer Out & Attach The Drawer
Housing To Counter Top With Appropriate Fasteners.



NOTE: The Drawer Slide Needs To Be Greased A Minimum Of Every 6 Months. Lithium Soap Based Grease No. 2 Is Recommended. Open The Drawer To Access The Grease Fitting.

